VPI University Program

Photonics Curriculum Version 7.0

Lecture Series



Introduction to Optical Receivers

Rx1

Copyright VPIsystems. All rights reserved.



Module Prerequisites

- Introduction to Fiber-Optic Communications I & II
- Recommended Transmitters I, Optical Amplifiers I

Module Objectives

- Introduction and basic requirements
- How a photodetector works
 - Basic structure: a PN junction photodetector
 - Optical Absorption Process
 - Reverse Bias, Dark Current, Quantum Efficiency, Responsivity
- PIN and APD photodetectors
- Noise sources



Photodetectors


A photo detector (optical receiver) converts an optical signal into an electrical signal

Basic requirements

- Sensitivity at the required wavelength
- Efficient conversion of photons to electrons
- Small area for low capacitance and a fast response
- Low noise
- Sufficient area for efficient coupling to optical fiber
- High reliability
- Low cost



Basic Structure:






The Probability of Photon Absorption

Depends on

- Thickness of intrinsic region, d
- The material's absorption coefficient, α
- The wavelength of the incident light, λ
- No. of photons lost on their way to the intrinsic region
- Surface reflection




Absorbed photons/s $A(1-exp(-\alpha d))$



Reverse Bias and Photocurrent

Reverse biasing the photodetector


- Increases the electric field in the depletion region
- Decreases its capacitance (increase speed)
- Increases its sensitivity and frequency response





Absorption


Absorption coefficient depends on wavelength, and the material (bandgaps again)





Dark Current

- Dark current (flows even when there is no light)
- As the incident light increases...
 the photocurrent increases linearly





Quantum Efficiency

The quantum efficiency (η) is the probability that an incident photon will produce an electron-hole pair

```
\eta = electron flux / photon flux
```



Responsivity

The responsivity, R_0 (A/W), is the photocurrent produced per unit of incident optical power

$$R_0 = I_p/P_i = q\eta/hf$$
 [A/W]
with $I_p =$ (electron flux) • q [A]
 $P_i =$ (photon flux) • hf [W]

The responsivity of a device relates to its design:


$$R = (1 - r) \exp(-D\alpha_c) [1 - \exp(-d\alpha)] (q\lambda/hc)$$

Facet Contact Intrinsic Wavelength factor absorption absorption factor



Responsivity & Wavelength Dependence

Different materials suit different wavelengths






PIN Photodetector

Adding an "intrinsic" region between P and N

- increases depletion region width
- increases absorption of incident light
- increases the quantum efficiency of the photo detector






Speed of PIN Photodetector

Speed - maximum detectable modulation rate

• i.e. the electrical frequency response

Speed is limited by the:

- Carrier velocity in depletion region
- Diffusion time of carriers outside the depletion region
- Time constant of the p-n junction capacitance
- Photodetector load resistance






Avalanche Photodetector (APD)

Avalanche region - higher internal electric field

- Accelerates carriers more kinetic energy
- High energy collision frees bound electrons
- Freed electrons can collide free more bound electrons
- Results in current gain (avalanche multiplication)





Comparison between APD & PIN

An APD:


- has gain, while a PIN does not
- can detect a weaker signal than a PIN
- requires a higher bias voltage than a PIN
- is noisier than a PIN
- is more sensitive to variations in temperature and bias voltage than a PIN
- is more expensive than a PIN



Electronic Shot Noise

- associated with the quantum nature of the light
- each incident photon produces an electron's worth of current.

The total shot noise associated with a photocurrent current *I* flowing through a potential barrier is:






Thermal Noise

- is the result of thermally induced random fluctuations in the charge carriers in a resistance
- occurs even when no voltage is applied across the resistance

Mean square thermal noise current is given by:





Dark Current Noise I_d

- flows in the photo detector even in the absence of light.
- caused by current leakage paths in the photo detector
- and thermal excitation of carriers across the p-n junction

 I_d gives rise to an additional shot noise current with a mean-square value of:

$$\langle i^2_{dark} \rangle = 2qI_dB$$



APD Excess Noise

 is present in avalanche photodiodes because the avalanche multiplication is essentially a random process

This causes the shot noise of the photodiode to be multiplied by:

Noise Multiplication factor =
$$M^{2+x}$$

(0.1 < x < 1.0)

where M is the avalanche gain



Optical Excess Noise

 can be broadly defined as any noise that appears along with the received signal, other than quantum shot-noise

Most common types:

- Laser Intensity Noise
- Modal Noise
- Mode Partition Noise
- Amplified Spontaneous Emission (ASE) Noise in optical amplifiers



Signal-to-Noise Ratio (SNR)

Electrical SNR (assuming shot noise dominates)

$$P_{in}$$
 $i_{signal} + i_{shot}$

$$\langle i^2_{shot} \rangle = 2qIB = 2qR_0P_{in}B$$

$$i^2_{signal} = (R_o P_{in})^2$$


SNR =
$$\frac{(R_o P_{in})^2}{2qR_o P_{in}B} = \frac{P_{in}}{2hfB}$$

 $R_0 = \frac{q}{hf}$, Responsivity of the photodetector



SNR in Optical Systems

Mixing products in the detected photocurrent:





Total SNR of Optical Systems

The SNR at receiver with responsivity R_o , and electrical bandwidth B

$$SNR = \frac{i_s^2}{(i^2_{s-sp} + i^2_{sp-sp} + i^2_{shot}) + i^2_{ther})B}$$

includes contributions from i_d , i_{ASE} , optical excess noise induced shot noise



Summary

- How a basic PN junction photodetector works
 - Optical Absorption Process
 - Reverse Biasing, Photocurrent, Dark Current
 - Quantum Efficiency, Responsivity
- How PIN photodetectors and APDs work
- Overview of noise sources in photodetectors
- Signal to Noise Ratio

Proceed with the Interactive Learning Module